



UCI PAINTS, Florida's Paint Manufacturer

DIV. OF UNION CHEMICAL INDUSTRIES

Architectural Coatings • Deck Coatings • Sundries • Waterproofing Systems

1320 NW 23rd Avenue • Fort Lauderdale, Florida 33311

Toll Free: 800-273-1683 • Broward: 954-581-6060 • Fax: 954-581-6085

[www.ucipaints.com](http://www.ucipaints.com)

## AQUA- STAIN

# CLEAR, SEMI-TRANSPARENT, OR SOLID BODY PENETRATING WOOD STAIN & PRESERVATIVE #39-000

**Recommended Uses:** UCI'S AQUA-STAIN is a state of the art water based wood stain or preservative. AQUA-STAIN will penetrate in to non-coated wood surfaces. AQUA-STAIN is formulated to be used on vertical wood or horizontal deck surfaces (which has walking traffic). AQUA-STAIN cannot be used on areas that have heavy vehicular traffic. AQUA-STAIN may be used on interior of exterior surfaces. The high concentration of proprietary mildewcides and algaecides provides excellent protection against the tropical elements while preserving the grained and natural beauty of the wood surface to which it is applied, AQUA-STAIN is recommended for use on wood siding, furniture, paneling, floors, cabinets and other wood surfaces.

**Limitations:** Check compatibility when applying over previous coats of paint.  
Best suited for use on unpainted wood surfaces.

**Description:** A proprietary ultra- fine particle size 100% Acrylic water based vehicle that is VOC compliant and environmentally friendly. AQUA-STAIN's finish can be clear, semi- transparent, or a solid pigmented stain. AQUA-STAIN is modified with special additives to preserve and protect wood substrates from UV degradation, and protect the film form mildew and algae growth.

**Finish:** A low luster, clear, semi- transparent or a solid color opaque finish

**Surface Preparation:** Surface must be clean and free of dirt or dust. Wood previously painted, varnished or waxed must be stripped down to bare wood (for a semi transparent finish). using paint and varnish remover. The wood surface should then be sanded smooth. Nails should be counter-sunk, holes puttied or spackled, sanded smooth and dusted clean.

**Coverage:** Depends upon depth of color desired and porosity of surface.

**Application:** Interior: Stir well before and during use. Apply by brush or rag. Color can be varied by amount of stain applied and by wiping with a cloth before the stain dries. Do not allow a "surface film" to remain. Wipe excess stain from surface evenly to prevent a painted appearance. For a gloss effect or added protection, you may apply one or more coats of UCI 47-0000 ULTRA-TUFF water based varnish over the stained wood.

**Exterior:** Stir well before and during use. For best results, apply over bare wood with a wide flat brush, roller, or by airless spray. Color can be varied by quantity of stain applied to the surface.

**Thinning:** Apply at package consistency. If necessary, may be thinned slightly with water.  
. Do not add any mineral spirits or other solvents.

**Drying Time:** Dry to touch in one hour. May be over coated after 4 hours.

**Clean Up:** Clean up brushes and equipment with soap & water.

n:\udata\3\94\39-000