



1-800-273-1683

www.ucipaints.com

Paints Made to Last in The Florida Sun

#75-400

STUKO-LASTIC TEXTURED KNIFE GRADE MASONRY PATCH

STUKO-LASTIC TEXTURED KNIFE GRADE ELASTOMERIC PATCHING COMPOUND is a 100% Acrylic knife grade textured patch that is an internally plasticized (no additional plasticizers added) elastomeric patching membrane. Dirt pickup is minimized via a photo initiator and once dry, the ingredients contained within the membrane will not leach out and discolor the finish coat.

STUKO-LASTIC is formulated for patching cracks (1/32" to 1/4") in masonry & stucco substrates. When applied properly STUKO-LASTIC will seal and waterproof masonry and joints between wood, glass, and brick.

TYPICAL USES: Waterproofing & Patching textured masonry & stucco substrates to include cracks, joints, seams, roofs, and parapet flashings. Excellent use for waterproofing seams between dissimilar substrates such as galvanized, aluminum, and glass to masonry or concrete.

CHARACTERISTICS: Very viscous, textured, trowelable, and high solids compound. May be applied in thick films without slump. Minimal shrinking, permanently flexible and paintable. STUKO-LASTIC has superior adhesion and is mildew and algae resistant.

CLEAN UP: Wash all equipment with warm detergent solution and rinse with water.

TECHNICAL DATA

FINISH: Low Sheen Textured

VEHICLE TYPE: 100% Acrylic Elastomer

COATING SOLIDS BY WEIGHT: 67%

VOLUME: 59%

VISCOSITY: 160KU

FINISH: TEXTURED

VOC: Less than 100 grams per liter

All cracks should be sounded out to determine if hollow or delamination of the stucco is present.

ALL PATCHING OF CRACKS WILL BE DONE AFTER SURFACES ARE PROPERLY PREPARED AND SEALED TO ENSURE THE ADHESION OF ANY PATCHING MATERIAL. WHEN FILLING JOINTS OR CRACKS BE SURE TO "CROWN" THE PATCHING COMPOUND SO THAT A SMALL CREST REMAINS. THIS WILL COMPENSATE FOR ANY SLIGHT SHRINKAGE THAT MIGHT OCCUR.

DO NOT USE BELOW GRADE OR UNDER WATER. DO NOT APPLY when temperature of air and surface is BELOW 40 degrees (F).
Use caution if rain is imminent, patch needs at least 4 hours of dry time. Allow new (fresh) concrete to cure for thirty days or prime with UCI #56-140 "Rain-Kote", be sure to force Rain-Kote into crack.