



Florida's Paint Manufacturer
Architectural Coatings • Deck Coatings • Roof Coatings • Sundries • Waterproofing Systems

1320 NW 23rd Avenue • Fort Lauderdale, Florida 33311
Broward: 954 581-6060 • Dade: 305 945-4300 • Boca: 561 428-5833
Toll Free: 800 273-1683 • Fax: 954 581-6085

POXY-PATCH

TWO PART 100% SOLIDS EPOXY CEMENT PATCHING COMPOUND

75-900

DESCRIPTION & USES: A durable two component high performance industrial grade 100% solids solvent epoxy cement patch and bonding paste. POXY-PATCH is formulated to fill cracks and voids in cement substrates such as catwalk decks, balustrades, or structural columns & beams. POXY-PATCH can also be used to bond cementitious substrates together. A unique feature of Poxxy-Patch is that it can also be used under water to patch cracks or as an anchoring cement. POXY-PATCH dries to a hard, durable, non leaching rigid membrane filler and anchoring cement. POXY-PATCH can be factory tinted to custom match color to adjacent areas.

MIXING INSTRUCTIONS :

POXY-PATCH is a two component epoxy that MUST be mixed thoroughly prior to use.

MIX EQUAL QUANTITIES OF PART A AND PART B. MIX THOROUGHLY UNTIL COLOR IS UNIFORM. LET MIXTURE SIT OR DWELL FOR 2-5 MINUTES. POXY -PATCH IS THEN READY FOR USE. MIXTURE SHOULD BE USED WITHIN A FIFTEEN MINUTE WINDOW, OTHERWISE IT WILL BEGIN TO SOLIDIFY AND NOT SELF LEVEL.

APPLICATION TECHNIQUES:

All surfaces must be clean and dry and general preparation procedures followed. Cracks that are to be filled should be V'd out and cleaned thoroughly. POXY-PATCH should then be poured or knifed into crack. Poxxy-Patch is self leveling and non shrinking. The crack should be filled in its entirety and level with the adjacent surfaces. For bonding, apply POXY-PATCH to both sides of substrate and then press together. Set time is approximately 25 minutes. Allow to cure at least two hours for full strength. The greater the mass of POXY-PATCH the faster the set time. A thin layer will take longer to set and cure than a 1 inch patch.